



92502爆炸图

11-18-2006

SPARE PARTS FOR CM0349 / KS 70 - FLIP OVER SAW

Pos No	HTNW NO	Part No Supplier	Quantity	Part Name English
1	95112050	JF-92502-0001	4	Rubber pad
2	95112051	JF-92502-0002	4	Support leg
3	95112052	JF-92502-0003	1	Plug cable
4	95112053	JF-92502-0004		Grommet
5	95112054	JF-92502-0005	4	Tighten knob
6	95112055	JF-92502-0006		Adjustable bracket
7	#/I/T	JF-92502-0007	2	Side plate
8	95112056	JF-92502-0008		Fixing board
9	95112057	JF-92502-0009		Square-neck bolt
10	95112058	JF-92502-0010		Lead clamp
11	95112059	JF-92502-0011		Hesagonal screw
12	95112060	JF-92502-0012		Spring washer
13	95112061	JF-92502-0013		Washer
14	95112062	JF-92502-0014		Lead clip
15	95112063	JF-92502-0015		Screw
16	95112064	JF-92502-0016		Label
17	95112065	JF-92502-0017		Pipe
18	95112066	JF-92502-0018		Screw
19	95112067	JF-92502-0019		Switch cover
20	95112068	JF-92502-0020		Screw
21	95112069	JF-92502-0021		Magnet switch
22	95112070	JF-92502-0022		Switch box
23	95112071	JF-92502-0023		Screw
24	95112072	JF-92502-0024		Spring washer
25	95112073	JF-92502-0025		Washer
26	95112074	JF-92502-0026		T fixing plate
27	95112075	JF-92502-0027		fixing bushing
28	95112076	JF-92502-0028		Label A
29	95112077	JF-92502-0029		Label B
30	95112078	JF-92502-0030		Transfer switch box
31	95112079	JF-92502-0031		Transfer switch
32	95112080	JF-92502-0032		Anchorage
33	95112081	JF-92502-0033		transfer switch cover
34	95112082	JF-92502-0034		Screw
35	95112083	JF-92502-0035		Screw
36	95112084	JF-92502-0036		Lock block
37	95112085	JF-92502-0037		Twisting spring
38	95112086	JF-92502-0038		Screw
39	95112087	JF-92502-0039		Fixing block
40	95112088	JF-92502-0040		Pin
41	95112089	JF-92502-0041		Square-neck nut
42	95112090	JF-92502-0042		Lock knob
43	95112091	JF-92502-0043		Lock block
44	95112092	JF-92502-0044		Scale A

Pos No	HTNW NO	Part No Supplier	Quantity	Part Name English
45	95112093	JF-92502-0045		Rotating base
46	95112094	JF-92502-0046		Angle scale A
47	95112095	JF-92502-0047		Scale B
48	#/T	JF-92502-0048		Table
49	95112096	JF-92502-0049		Angle scale B
50	95112097	JF-92502-0050		Screw
51	95112098	JF-92502-0051		Indicator
52	95112099	JF-92502-0052		Screw
53	95112100	JF-92502-0053		Screw
54	95112101	JF-92502-0054		Label C
55	95112102	JF-92502-0055		Scale C
56	95112103	JF-92502-0056		Pin
57	95112104	JF-92502-0057		Screw
58	95112105	JF-92502-0058		Angle bracket
59	95112106	JF-92502-0059		Scale D
60	95112107	JF-92502-0060		safety guard
61	95112108	JF-92502-0061		Screw
62	95112109	JF-92502-0062		Spring washer
63	95112110	JF-92502-0063		Washer
64	95112111	JF-92502-0064		Fixing collar
65	95112112	JF-92502-0065		Steel ball
66	95112113	JF-92502-0066		Lock spring
67	95112114	JF-92502-0067		Screw
68	95112115	JF-92502-0068		Fence
69	95112116	JF-92502-0069		Side fence A
70	95112117	JF-92502-0070		Side fence B
71	95112118	JF-92502-0071		Lock knob
72	95112119	JF-92502-0072		Fixing cover
73	95112120	JF-92502-0073		Fixing spring
74	95112121	JF-92502-0074		Lock knob
75	95112122	JF-92502-0075		Plastic screw
76	95112123	JF-92502-0076		Lock nut
77	95112124	JF-92502-0077		Fixing collar
78	95112125	JF-92502-0078		Plate bearing
79	95112126	JF-92502-0079		Washer
80	95112127	JF-92502-0080		Bracket pointer
81	95112128	JF-92502-0081		Bracket link
82	95112129	JF-92502-0082		Fixing scerw
83	95112130	JF-92502-0083		Bracket connector
84	95112131	JF-92502-0084		Clamp ass
85	95112132	JF-92502-0085		Pin
86	95112133	JF-92502-0086		Fixing ring
87	95112134	JF-92502-0087		Twisting spring
88	95112135	JF-92502-0088		Angle scale
89	95112136	JF-92502-0089		Head bracket
90	95112137	JF-92502-0090		Screw
91	95112138	JF-92502-0091		Rolling ring

Pos No	HTNW NO	Part No Supplier	Quantity	Part Name English
92	95112139	JF-92502-0092		Link bar
93	95112140	JF-92502-0093		Bearing
94	95112141	JF-92502-0094		Pin
95	95112142	JF-92502-0095		Nut
96	95112143	JF-92502-0096		Screw
97	95112144	JF-92502-0097		Stop pin
98	95112145	JF-92502-0098		Pin
99	95112146	JF-92502-0099		Spring
100	95112147	JF-92502-0100		Ball knob
101	95112148	JF-92502-0101		Lock nut
102	95112149	JF-92502-0102		Stop bracket
103	95112150	JF-92502-0103		Fixing collar
104	95112151	JF-92502-0104		Screw
105	95112152	JF-92502-0105		Adjust knob
106	95112153	JF-92502-0106		Adjust bushing
107	95112154	JF-92502-0107		Adjust rod
108	95112155	JF-92502-0108		Fixing wheel
109	95112156	JF-92502-0109		Fixing pin
110	95112157	JF-92502-0110		Spring
111	95112158	JF-92502-0111		Transparent guard
112	95112159	JF-92502-0112		Retaining ring
113	95112160	JF-92502-0113		Screw
114	95112161	JF-92502-0114		Washer
115	95112162	JF-92502-0115		Riving knife ass
116	95112163	JF-92502-0116		Fixing block
117	95112164	JF-92502-0117		Pin
118	95112165	JF-92502-0118		Lock knob
119	95112166	JF-92502-0119		Retaining ring
120	95112167	JF-92502-0120		Rear cover
121	95112168	JF-92502-0121		Carbon brush cover
122	95112169	JF-92502-0122		Carbon brush
123	95112170	JF-92502-0123		Carbon brush holder
124	95112171	JF-92502-0124		Screw
125	95112172	JF-92502-0125		Housing
126	95112173	JF-92502-0126		Stator
127	95112174	JF-92502-0127		Screw
128	95112175	JF-92502-0128		Bearing
129	95112176	JF-92502-0129		Armature
130	95112177	JF-92502-0130		Wind guard
131	95112178	JF-92502-0131		Lock guard
132	95112179	JF-92502-0132		Shaft lock
133	95112180	JF-92502-0133		Lock spring
134	95112181	JF-92502-0134		Bearing
135	#/T	JF-92502-0135		Head guard
136	95112182	JF-92502-0136		Label D
137	95112183	JF-92502-0137		Bearing
138	95112184	JF-92502-0138		Retaining ring

Pos No	HTNW NO	Part No Supplier	Quantity	Part Name English
139	95112185	JF-92502-0139		Big gear
140	95112186	JF-92502-0140		Retaining collar
141	95112187	JF-92502-0141		Spindle
142	95112188	JF-92502-0142		Key
143	95112189	JF-92502-0143		Retaining ring
144	95112190	JF-92502-0144		Bearing flange
145	95112191	JF-92502-0145		Bearing
146	95112192	JF-92502-0146		Screw
147	95112193	JF-92502-0147		Label E
148	95112194	JF-92502-0148		Link block
149	95112195	JF-92502-0149		Twist spring
150	95112196	JF-92502-0150		Dust-prot block
151	95112197	JF-92502-0151		Link pin
152	95112198	JF-92502-0152		Screw
153	95112199	JF-92502-0153		Retaining wheel
154	95112200	JF-92502-0154		Bearing flange
155	95112201	JF-92502-0155		Screw
156	95112202	JF-92502-0156		Transparent guard
157	95112203	JF-92502-0157		Pull spring
158	95112204	JF-92502-0158		Retaining ring
159	95112205	JF-92502-0159		Inner flange
160	#/T	JF-92502-0160		Blade retaining ring
161	#/T	JF-92502-0161		Blade
162	95112206	JF-92502-0162		Outer flange
163	95112207	JF-92502-0163		Special fixing bolt
164	95112208	JF-92502-0164		retaining spring
165	95112209	JF-92502-0165		Retaining block
166	95112210	JF-92502-0166		Screw
167	95112211	JF-92502-0167		Dust exit
168	95112212	JF-92502-0168		Lock spring
169	95112213	JF-92502-0169		Twist shaft
170	95112214	JF-92502-0170		Lock
171	95112215	JF-92502-0171		Lock collar
172	95112216	JF-92502-0172		Screw
173	95112217	JF-92502-0173		Down handle
174	95112218	JF-92502-0174		Switch
175	95112219	JF-92502-0175		Capacitor
176	95112220	JF-92502-0176		Inductor
177	95112221	JF-92502-0177		Switch trigger
178	95112222	JF-92502-0178		Selt lock knob
179	95112223	JF-92502-0179		Cable clamp
180	95112224	JF-92502-0180		Lock block
181	95112225	JF-92502-0181		Up handle
182	95112226	JF-92502-0182		Screw
183	95112227	JF-92502-0183		Label F
184	95112228	JF-92502-0184		Label G
185	95112229	JF-92502-0185		Cable